

Mobile Dispensing Equipment & Party Kegs



PAULANER
BRÄUHAUS
Singapore

1. Mobile Dispenser Unit

W x D x H	84 x 60 x 150 [cm]
Weight	85 [kg]
Electrical Requirement	220 [V]



2. Portable Dispenser Unit

W x D x H	30 x 50 x 48 [cm]
Weight	27 [kg]
Electrical Requirement	220 [V]



Mobile Dispensing Equipment & Party Kegs



PAULANER
BRÄUHAUS
Singapore

3. Party Keg 20 ltr.

Diameter 37 [cm]
H 42 [cm] (without air vent)



4. Party Keg 30 ltr.

Diameter 44 [cm]
H 45 [cm] (without air vent)



Accessories for Party Kegs

Mobile Dispensing Equipment & Party Kegs




PAULANER
BRÄUHAUS
Singapore



Handling of Fittings for Party Kegs



PAULANER
BRÄUHAUS
Singapore



How to tap the Partykeg

1. Place rubber seal in lower opening of keg
2. Make sure tap is closed by pointing handle inwards
3. Firmly push tap into rubber seal in lower opening of keg. Do not use a hammer!
4. Place glass under tap, and turn handle forward until beer flows out
5. If beer flows too slowly, slide "breather cap" onto metal fitting on top of keg and turn it clockwise to let air in
6. Remove tap after use

Tips:

- a) The keg automatically closes when tap is removed
- b) Rubber seal can remain in keg if it does not come out with tap

