

HOW TO TAP THE PARTY KEG

1. Place rubber seal in lower opening of keg
2. Make sure tap is closed by pointing handle inwards
3. Firmly push tap into rubber seal in lower opening of keg. Do not use a hammer!
4. Place glass under tap, and turn handle forward until beer flows out
5. If beer flows too slowly, slide “breather cap” onto metal fitting on top of keg and turn it clockwise to let air in
6. Remove tap after use

TIPS:

- a) The keg automatically closes when tap is removed
- b) Rubber seal can remain in keg if it does not come out with tap



PAULANER BRÄUHAUS SINGAPORE

For reservations please call: +65 6883 2572
Email: info@paulaner-brauhaus-singapore.com
www.paulaner-brauhaus-singapore.com